



# MANUAL

Bluetooth-Sport-Headset



Image is an example only

Product number: EP18120

---

## PACKAGE CONTENT

Congratulations on the purchase of your new device. Before attempting to use the device read the instructions carefully and make sure the following objects are included in the packaging:

Pieces	Accessory	Note
1	Wireless headset	integrated battery
1	Micro USB cable	-
1	Manual	-
4	Silicone Ear tip	-

## TECHNICAL DETAILS

Data connection	Bluetooth 5.0
Frequency range	2.402 Ghz – 2.480 GHz
Frequency	UHF
max. transmission	2.92 mW
Transmission range	10m
Run time	up to 6 hours
Stand-by time	up to 100 hours
Charging time	ca. 1,5 h

## FUNCTION

Press the power button for 2-4 seconds to turn the headset on or off.




on

## PAIRING

Power on the headset. The display flashes red and blue. Search and then select "LEICKE EP18120 " in the Bluetooth menu of your phone. If a code is required, simply enter "0000".

## CONTROL AND OPERATION



---

## INCOMING CAL

Shortly press button "①" to answer / hang up the call.

Double press the button "③" twice - to reject the call.

Pressing button "③" shortly twice recalls the last dialed number.

## VOICE ASSISTANT

Double press the button "①" to enter the Siri/Google assistant.

## VOLUME CONTROL

You can reduce the volume by pressing the "③" key for 1-2 seconds.

Increase the volume by pressing the key "②" for 1-2 seconds.

## MUSIC CONTROL

Briefly press the "①" key to play or pause the music.

Briefly press the "②" key to switch to the previous track.

Briefly press the button "③" to switch to the next music track.

---

## **LOW BATTERY WARNING**

When the battery is low, an alarm sounds - "Battery low, please charge".

## **CHARING THE HEADSET**

Connect the device to a USB port with the charging cable. When the battery is fully charged, the red LED light turns blue.

## **SAFETY NOTES**

For your own safety and for long enjoyment of our product, please follow the following safety instructions:

- Please use device as described in the manual.
- Please keep the device dry and use in dry environment only. Do not touch with wet hands.
- Keep away from damp, high temperature, dusty, erosive and oxidative environment.

Do not open cover and do not touch inner parts

---

## DISPOSAL

This device contains materials that must not be disposed of as household waste. Please check local laws concerning the applicable disposal regulations. Protect the environment by participating in recycling programs.



## DECLARATION OF CONFORMITY

LEICKE GmbH herewith declares that the devices comply with the RED 2014/53/EU and ROHS 2011/65/EC & 2015/863 & 2017/2102 regulations. The declaration of conformity can be found at:

[www.leicke.com/de/products/EP18120](http://www.leicke.com/de/products/EP18120)



## CONTACT

**If you have any questions, please feel free to contact us.**

**LEICKE GmbH**  
Dohnanyistr. 28  
04103 Leipzig  
Germany

**Web: [www.leicke.com](http://www.leicke.com)**  
**Mail: [info@leicke.com](mailto:info@leicke.com)**

