



3



4



5

✓

!

TV

✗

TV

TV

+

DE

EN

FR

ES

IT

Oberseite

Top

Toupie

Cima

Vetta

M-A

M-B

M-C

DE

EN

FR

ES

IT

Benutzen Sie die für Ihren Bildschirm passenden Schrauben und Abstandshalter.


Use the matching screws and spacers for your display.

Utilisez les vis et les entretoises appropriées pour votre écran.


Use los tornillos y espaciadores apropiados para su pantalla.

Utilizzare le viti e i distanziali appropriati per lo schermo.


6



7



8



DE Fertig!
EN Done!
FR Fait!
ES Hecho!
IT Fatto!

