


SKU#
64585
64586
64587
64588
64589
64590
64591
64592
64593

ASSEMBLY INSTRUCTIONS















Parts & Hardware

Avoid using sharp objects such as knife to cut open packing, as you may accidentally damage the

Teile Liste

Öffnen Sie die Kartons nie mit einem scharfen Gegenstand, um Beschädigungen am Artikel zu vermeiden.

 <p>A. Top 1x</p>	 <p>B. Front 1x Back 1x</p>	 <p>C. Box Side 1x</p>	 <p>C1 Box Side 1x</p>
 <p>D. Bottom 1x</p>	 <p>E. Trunk Strut 2x</p>	 <p>M6*40 F. Bolt 18x Washer 18x</p>	
 <p>M6*20 G. Bolt 4x Washer 4x</p>	 <p>H. Nut 2x</p>	 <p>I. Box Case 1x</p>	
 <p>J. Allen Key 1x</p>	 <p>K. Wrench 1x</p>		

ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.

Do not tighten the screws in the individual steps yet. Please pre-align the screws first in all directions and secure them with the accompanying nuts. After all screws are in place at the destination, you can tighten them. During the production of your item, it is unfortunately inevitable that the tolerances, which can be caused by the rattan tensioning, lead to the fact that during assembly the holes do not always lie 100% opposite each other. Please try with gentle force to push the item through the frame by pushing it slightly in the direction of the arrows.

