



Manual

USB Quick Car Charger PD+QC3.0



Product number: AA30058

PACKAGE CONTENT

Congratulations on the purchase of your new device.

Before using this device, please check the package and make sure that the following parts are included in the package:

Number	Part	Note
1	USB Quick Car Charger	-
1	Manual	-
1	3 in 1 Multi USB cabel	

PRODUCT INFORMATION

- The USB car quick charger is connected via the car cigarette lighter. Many cars do not have a USB charging port, so the USB quick car charger is a reliable helper. It is easy to install. There is a USB-A port and a USB-C port for various smartphone, tablet models and other USB devices.
- The USB charger is suitable for charging/operating with a USB charging socket via a 12V / 24V car socket.
- The device is not intended for commercial use.
- Any other use or modification of the device is considered improper and involves significant risks.
- The manufacturer accepts no liability for damage resulting from improper use.

TECHNICAL DETAILS

Input	DC 12V - 24V
Power output	QC3.0 18W + PD 18W = 36W
USB-C PD	DC: 5V/3A 9V/2A 12V/1.5A
USB-A QC3.0	DC: 5V/3A 9V/2A 12V/1.5A
Overload protection	Input: $\leq 8V$, $\geq 33V$; Output USB-A / USB-C: automatic shutdown in case of short circuit, Overtemperature protection
Current limit	PD, QC3.0 $\leq 4A$
Operating temperature range	-25° - 40°C
Permissible relative humidity	0% - 90%
Dimensions	Length: 62mm Diameter 25mm
Product weight	20g

IMPORTANT NOTES

- Please read the operating instructions carefully before using the device
- Please check the manual of your device to be connected (e.g. smartphone) if it is compatible and the input voltage of the device to be connected is suitable for the output voltage of the adapter.

- The maximum output power of the USB car quick charger is 36W in total, 18W for each output PD or QC3.0 independently.
- This adapter may only be operated with the permissible DC voltage 12V - 24 V.
- Do not use the adapter if the housing is damaged.
- Disconnect the adapter from the cigarette lighter socket when not in use.

CLEANING NOTES

- To remove dust or other dirt, please use a dry, soft cloth.
- Never use chemicals, solvents or aggressive cleaning agents to clean the device in order to avoid damage and malfunctions. Do not place the device near to liquid, moisture, humidity or rain while charging
- Avoid contact with sharp-edged objects to prevent scratches.

SAFETY NOTES

- Do not cover the device during operation and ensure that there is sufficient ventilation.
- Do not connect devices to the USB car quick charger that require more power than the output power specified in the technical details.
- The device must not be subjected to loads such as shocks, impacts, dropping, high and very low temperatures, bending or pressure loads.
- Please check the proper condition of the device and the cables before each use.
- If damage is evident, the device must not be used under any circumstances.
- The device must not be exposed to liquids, high humidity or rain. The device must not be stored or operated near heat sources, cooking areas or open fires.
- Keep the device away from children.
- Do not use the device outdoors.
- The device has no parts that require maintenance. It must not be opened or disassembled

DISPOSAL

This device contains materials that must not be disposed of as household waste. Please check local laws concerning the applicable disposal regulations. Protect the environment by participating in recycling programs!



Declaration of Conformity

LEICKE GmbH herewith declares that the devices comply with the EMV 2014/30/EU LVD 2014/35/EU and ROHS 2011/65/EC regulations. The declaration of conformity can be found at: www.leicke.com/de/products/AA30058



CONTACT

If you have any questions, please feel free to contact us.

PRODUCTION & WHOLESALE

LEICKE GmbH
Dohnanyistr. 28
04103 Leipzig
Germany

Web: www.leicke.com
Mail: info@leicke.com

